


BARACUDA MX 8



BARACUDA MX 8

<i>detail</i>	<i>identifikace</i>	<i>popis</i>
1	W79032P	Hose Float
2	W79033P	Clip-on hose adaptator
3	W79018	Top cover/swivel assembly
4	W79035	Screw m4x12mm philips #2 pan head
5	W79066	Middle drive motor housing 1
6	W79027	Cover latch 1
7	W79035	Screw m4x12mm philips 2 pan head
8	W79030	Body panel - right
9	W79015	Drive shaft assembly
10	W79034	Bearing (wheel engine)
11	W79013	Drive motor assembly
12	W79022	Lower drive motor housing - side A - B
13	W79036	Screw thread forming 6-18 7/8in
14	W79020	Body panel - rear
15	W79012	Reversing assembly - side B
16	W79025	Track
17	W79065	Wheel pin
18	W79024	Wheel
19	W79011	Reversing assembly - side A
20	W79031	Body panel - left
21	W79062	Chassis assembly
22	W79021	Lower body housing
23	W79019	Body panel - front
24	W79014	Scrubber assembly
25	W79017	Inlet assembly
25B	W79047P	Regular opening
26	WA0235200	Wheel speed indicator
27	W78055	Set of 6 1 meter twist lock hoses
28	W60055P	Automatic flow adjustment valve
29	W69657P	In-ground valve cuff
30	W73011P	Twist-lock 45 deg elbow extended
31	W70244	45 deg elbow